

Functional Style

This heavy duty system provides ample opportunity for upgrades. Choose white or satin nickel finish. Its fast and easy to install.



RAILS

For use with FastTrack® Uprights.

40" FastTrack® Rail – White	FG3Q7000WHT
40" FastTrack® Rail – Satin Nickel	1834282
80" FastTrack® Rail – White	FG3Q7100WHT
80" FastTrack® Rail – Satin Nickel	1834278

UPRIGHTS

Use to support brackets for shelving.

25" FastTrack® Upright – White	FG3Q7300WHT
47 1/2" FastTrack® Upright – White	FG3Q7400WHT
47 1/2" FastTrack® Upright – Satin Nickel	1834282
70" FastTrack® Upright – White	FG3Q7500WHT
70" FastTrack® Upright – Satin Nickel	1834281
81 1/4" FastTrack® Upright – White	1780151
81 1/4" FastTrack® Upright – Satin Nickel	1780152

BRACKETS

To support Rubbermaid® Wire Shelving.

12" Bracket – use on all 12" shelving plus 16" Wardrobe and FreeSlide shelving	
12" Bracket – White	1959952
12" Bracket – Satin Nickel	1959951
16" Bracket – use on 16" Linen and TightMesh shelving	
16" Bracket – White	1959955
16" Bracket – Satin Nickel	1959954
20" Bracket – use on 20" TightMesh shelving	
20" Bracket – White	1959957

RAIL HARDWARE

For mounting FastTrack® rail. Contains seven 12x2" screws, six 10x2" screws, seven anchors, four large plastic caps (5504), 20 small plastic caps (5503), and four extra small plastic caps (FG3P3800WHT).

FastTrack® Hardware Kit	FG3P56LWWHT
-------------------------	-------------

**Differentiate yourself with Rubbermaid
Closet Systems – call 1-877-533-1197**

RubbermaidPro.com

1913875



Rubbermaid®

Sturdy & Versatile

Rubbermaid® FastTrack® is ideal for storage spaces requiring greater flexibility and strength. FastTrack® is completely adjustable and works with all Rubbermaid® shelving types.



GREENGUARD

PRODUCT CERTIFIED FOR
LOW CHEMICAL EMISSIONS
UL.COM/GG
UL 2818

GOLD



The only GREENGUARD
certified wire shelving

Upgraded Shelving Options Are Easy As 1,2,3.

Step 1



Install rail at desired height using #12 x 2 1/2" screws and drywall anchors provided (88" is standard height measured from top of rail). Use 1/8" bit to drill pilot holes for screws going into studs, and use 1/4" bit to drill holes for drywall anchors.

Step 2



Hang uprights from the rail, spaced no more than 32" apart. Drill holes for stud or wall anchors and secure each upright in two locations using #10 x 2" or #12 x 2 1/2" screws (both size screws work with wall anchor).

Step 3



Insert brackets into uprights at desired locations and lock shelving into brackets.

Storage Made Easy

- Install any closet or pantry with minimum drilling
- Uprights don't require studs locations for installation
- Brackets and shelves lock into place for security and personalization
- FastTrack® can be adjusted as storage needs change without additional hole drilling

Storage Made Strong

Weight capacities:

- 100 lbs. * Per bracket (any size)
- 300 lbs. ** Per upright (any size)

*When mounting the rail properly into the studs.

**Additional weight holding capacity can be gained by attaching uprights to studs with screws.

***Cut shelving with no more than 8" of unsupported shelf at each end.